


## TO REPLACE MISSING SPLIT WASHER FROM AN EXTENDING CANE

1. Unscrew the tightening collar so that it moves freely along the shaft of the stick.
2. Open out the spare white split washer and place it around the bottom end of the shaft of the stick, above the tightening collar.



3. Move the tightening collar upwards, so that the split washer is fitted inside the tightening collar.
4. Screw the two sections of cane together normally. There should now be a snug fit between the two sections of the cane, with no rattling or movement within the cane.

**NB The split collars are sometimes lost when the two sections of the cane are taken completely apart. To avoid loss of this small but important component, Classic Canes recommends that the cane is not fully dismantled in future.**

If you require further assistance, please telephone + 44 (0)1460 75686 or email [customerservices@classiccanes.co.uk](mailto:customerservices@classiccanes.co.uk)

